

INSTALLATION MANUAL

LED WOWNLIGHT

G ADJUSTABL

CE RoHS © 🗵 🕸


200



AC220-240V | 50/60Hz | IP20 | Die cast

source: Power:

Do not operate with power supply connected.



Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.